

## READ THIS PAGE FIRST

1. **Howard-McCray would like to thank you for purchasing one of our units.**  
PLEASE READ THIS MANUAL CAREFULLY BEFORE PROCEEDING WITH THE INSTALLATION OR OPERATING OF THIS UNIT.
2. **Environment** - These display cabinets are made to operate at 75°F and 55% relative humidity. Temperature and/or humidity greater than the factory recommendations will hinder the performance of this cabinet.
3. **Cabinet Set-Up** – A qualified refrigeration mechanic should set-up this cabinet. Control settings are extremely critical to the proper operation of this unit. These settings are the responsibility of the customer and are not covered by factory warranties. Failure to have this unit installed by a qualified refrigeration mechanic may VOID all the warranties on this unit.
4. **Proper Loading** – Only pre-cooled foods should be placed in this unit.
5. **Location** – Because of the open area, this cabinet must not be located in the direct rays of the sun, near radiant heat sources, or in an area where it will be subjected to drafts or air disturbances of any type.
6. **Never spray water into the cabinet.** This will cause damage to the seals and cause the evaporator drain system to overflow.
7. **If additional assistance is required, please call us at 1-800-344-8222.**

## READ THIS PAGE FIRST

### 90-330 Island Open Series

# **Installation and Operating Instructions For**

## **Island Open Merchandiser**

### **Important Instructions**

**Please Read carefully  
Before attempting to  
install or operate the cabinet**

**Keep this Book for  
Future Reference**

**90-330 Island Open Series**

## Table of Contents

Engineering Specifications .....	4
General Specifications .....	5
Receiving and Inspection .....	5
Installation .....	6
Electrical Service Connection .....	6
Drain Installation .....	6
Sanitation .....	6
Remote Installation .....	6
Refrigeration Connection .....	7
Start-Up Check-List .....	7
Start-Up .....	7
Thermostatic Expansion Valve .....	7
Electronic Digital Controller .....	8
Electronic Digital Controller – Temperature .....	8
Electronic Digital Controller – Defrost .....	8
Loading Procedures .....	8
Maintenance Suggestions .....	8
The Cleaning Process .....	9
Machine Compartment Cleaning .....	9
Trouble Chart .....	10
Parts List .....	11-12
Customer Installation Record .....	13
Notes .....	14
Warranty Information .....	15-22
Electronic Controller Parameters (Settings) .....	23
Dixell Controller Manual XR40CX-A .....	24-27
Plan View SC/R-5FT .....	28
Plan View SC/R-7FT .....	29
Side View 5FT .....	30
Side View 7FT .....	31
Front View 5FT .....	32
Front View 7FT .....	33
Cabinet Wiring Diagram (5FT Self- Contained) 5G6500-LS .....	34
Cabinet Wiring Diagram (7FT Self-Contained) 7G6500-LS .....	35
Cabinet Wiring Diagrams (5FT Remote) 5G6500R .....	36
Cabinet Wiring Diagrams (7FT Remote) 7G6500R .....	37

## **Engineering Specifications – Self-Contained**

Model No.	Cabinet Dimensions D x H x L*	Compressor HP	Electrical Voltage	Max. Amps
SC-OD42I-5	42.0 x 60.0 x 60.0	1-1/2	115/208-230/60Hz/1PH	16.0
	1440 W Condensate Pan		115/60Hz/1PH	12.0
SC-OD42I-5-B	42.0 x 60.0 x 60.0	1-1/2	115/208-230/60Hz/1PH	16.0
	1440 W Condensate Pan		115/60Hz/1PH	12.0
SC-OD42I-7	42.0 X 60.0 X 84.0	1-3/4	115/208-230/60Hz/1PH	16.0
	1440 W Condensate Pan		115/60Hz/1PH	12.0
SC-OD42I-7-B	42.0 X 60.0 X 84.0	1-3/4	115/208-230/60Hz/1PH	16.0
			115/60Hz/1PH	12.0

1440 watt condensate pan requires a separate power supply.

## **Engineering Specifications – Remote**

Model No.	Cabinet Dimensions D x H x L*	Btu/Hr @ +20F	Refrigeration Connections (Liq - Suct)	Electrical Voltage	Max. Amps
R-OD42I-5	42.0 x 60.0 x 60.0	10,200	3/8" – 7/8"	115/60Hz/1PH	16.0
	1440 W Condensate Pan			115/60Hz/1PH	- -
R-OD42I-5-B	42.0 x 60.0 x 60.0	10,200	3/8" – 7/8"	115/60Hz/1PH	16.0
	1440 W Condensate Pan			115/60Hz/1PH	
R-OD42I-7	42 X 60 X 84	13,200	3/8" 7/8"	115/60Hz/1PH	16.0
	1440 W Condensate Pan			115/60Hz/1PH	
R-OD42I-7-B	42 X 60 X 84	13,200	3/8" 7/8"	115/60Hz/1PH	16.0
	1440 W Condensate Pan			115/60Hz/1PH	

**These cabinets are designed to operate in an  
air conditioned location ONLY.**

**Temperature NOT to exceed 75°F  
and a relative humidity not to exceed 55%.**

## **LOCATION OF CABINET IS VERY IMPORTANT**

**Because of the open area, this cabinet must not be located in the direct rays of the sun, near radiant heat sources, or in an area where it will be subjected to drafts or air disturbances of any type.**

# Howard-McCray

**The following instructions are for the benefit of the new owner and the installing contractor.**  
**They should be studied carefully before attempting to install or operate the cabinet.**  
**This manual is the property of the owner and should remain in the owner's possession.**

## **General Specifications and Features**

### ***Dimensions***

42 inches front to back by 84 inches left to right dimensions makes the cabinet ideal for convenient store installation. Height is optimized for maximum storage and merchandising appeal.

### ***Interior***

Aluminum interior surface, Stainless steel shelving and heavy gauge galvanized coil housing. The interior has a special finish process that prevents rusting.

### ***Exterior***

Black laminated exterior over durable heavy gauge galvanized steel. Easily cleanable. The standard is Black front and sides canopy and bottom grille.

### ***Refrigeration***

Refrigeration is proven, Howard-McCray KOLDFLO. KOLDFLO is the properly engineered control of temperature, humidity and air flow throughout, resulting in the product being constantly enveloped by cold air.

### ***Expansion Valve***

The expansion valve is located in evaporator housing in front of the cabinet and is readily accessible. There is no refrigeration tubing buried in the insulation.

### ***Drain***

The drain is a sink type with 1" Male NPT threads. A 1" PVC adapter, Drain Trap, into a condensate pan providing a self contained cabinet.

### ***Convenient Shopping***

Product is right in front of customer. Mass vertical display invites maximum selection. All adjustable shelves have a price tag strip taking 1 1/4 price tags, for pricing or calling attention to specials.

### ***Lighting***

LED lighting is standard under the canopy. All models utilize LED systems. LED Driver is located in the machine compartment in the large electrical box.

### ***Shelves***

Shelves are adjustable on 1" centers to fit the product requirements. An intergraded Front product stop is provided on each stainless steel shelf. The main deck shelf is also provided with a product stop to prevent the product from covering the return air system.

***Notes:*** This cabinet is designed for AIR CONDITIONED LOCATIONS ONLY, not to exceed 75°F and 55% RH.

## **Receiving and Inspection Procedure**

1) The cabinet has been carefully operation tested and inspected before crating and has been determined to be in good operating condition before leaving the factory.

2) Upon arrival of the cabinet, the crate should be inspected thoroughly for any damage that may have occurred in transit. In the event that any damage is discovered, it should be noted on the delivery ticket or Bill of Lading and signed to that effect. An immediate claim should then be filed against the carrier giving them the description and amount of damage.

3) After the crate has been removed, the cabinet should be examined carefully for any damage. If there is any concealed damage, the carrier should be notified immediately. Make a request in writing with the carrier for an inspection within 15 days, and retain all packaging. The carrier will supply the inspection report and the required claim forms.

4) Our Company can assume no responsibility for filing freight claims as the cabinet was in good condition on a clear Bill of Lading, F.O.B. Philadelphia. However, the factory will assist, if required.

5) Shortages - Check your shipment for any possible shortages of material. If one exists and is found to be responsibility of Howard-McCray, notify the factory. Howard-McCray will acknowledge shortages within ten days from receipt of acknowledgement. If a shortage exists and it involves the carrier, notify the carrier immediately and request an inspection.

## Installation

As with all open island display refrigerated cabinets, there are several very important requirements that must be complied with for proper operation. They are as follows:

1. This line of display cabinets are designed to operate in a location that is FULLY AIR CONDITIONED. Ambient temperatures must not exceed 75°F and the relative humidity must not exceed 55%. In addition, this cabinet should not be located in an area where it will be subjected to drafts or air disturbances of any type. Locations where the cabinet may be subjected to radiant heat from spot or flood lamps, sun rays or heat from suspended gas heating fixtures should be avoided.

2. After locating the cabinet, it must be leveled (using shims) from front to back as well as end-to-end. This will facilitate proper refrigeration at the evaporator and proper dissipation of the defrost water.

NEVER use a pry bar or jeep prongs on the bottom of end assemblies.

3. There must have clearance allowed around the base of the to allow the condensing unit to dissipate the heat. Make sure boxes are not placed against grille assemblies of the base.

4. All wiring must be installed by a competent electrician and conform to local codes. The incoming voltage must be maintained to within 5% of the voltage shown on the cabinet nameplate. The electrical service connection is to be made with a NEMA L14-20P plug for the condensing unit, lights and fans. If an electric condensate pan is provided, it must be supplied on a separate electrical circuit. Plugs are provided in the base of the machine compartment. Optional electrical plug connection can be provided along the top left of the cabinet (see applicable Plan View drawing).

## Electrical Service Connection

The electrical connection is to be made with the matching NEMA L14-20P. (see applicable Plan View drawing for exact location). The incoming voltage must be maintained to within 5% of the voltage shown on the nameplate. Howard-McCray will not accept responsibility for the performance of the cabinet or malfunction of any component due to a lower voltage supply than that indicated on the serial rating plate. Use separate electrical supply lines connected to a fuse block or circuit breaker of proper capacity.

## Drain Installation

When a electric condensate pan is not provided the following done. Properly installed drains are extremely important in ensuring satisfactory cabinet operation, and protection from product loss. The drains on these models must be pitched down a minimum of 1/4" per foot away from the cabinet. Never reduce the drain line size. Maintain the 1" pipe size for the entire length. Never double trap drain lines. Be sure that the drain lines are installed to comply with local codes. A 1" PVC drain trap is supplied with each Howard-McCray cabinet.

## Sanitation

Sanitation code compliance is necessary in many localities. It is recommended that the cabinet be sealed to the floor. Use a NSF Approved sealant between the floor and the perimeter of the cabinet base.

## Remote Installations

Remote installation of these cabinets require an experienced and knowledgeable refrigeration mechanic. The proper location, connection, and control of the cabinet is crucial for the cabinet to operate as designed.

Good refrigeration connection practices, as outlined in the *Refrigeration Connection* section.

The remote system is provided with an electric digital controller for proper cabinet temperature and for proper defrost periods.

Timely Defrosting of the evaporator coil is absolutely necessary to the proper operation of the cabinet.

## Refrigeration Connection (Remote Models)

The refrigeration tubing is located in the machine compartment base on the left side of the cabinet. A 7/8 OD suction line and a 3/8 OD liquid line is provided. These line sizes should not be reduced under any circumstances. The optional refrigeration connections can be provided on top of the cabinet on the left side. Refrigeration tubing location is shown on the Plan View drawing.

Points to remember when making the refrigeration connection:

1. Suction lines will sweat, therefore any lines not run in trenches or drained areas should be covered with Armaflex sleeving or equal.



## **Refrigeration Connection** **(Remote Models) Cont.**

2. When brazing tubing within the cabinet, use a piece of heat protective sheet to protect the galvanized pan from the heat. Heat applied to a galvanized pan will melt the insulation below it.
3. All copper tubing used should be of a refrigeration grade (type L or K), clean, dehydrated and sealed.
4. Always use a tubing cutter, never a hack saw or file. Remove the burrs from the inside of the tube.
5. Long radius fittings are preferable over short radius fittings.
6. Keep fittings and elbows to an absolute minimum.
7. All tubing runs should be free of kinks and restrictions and must be properly supported.
8. Silphos or equivalent silver alloy material is recommended for brazing copper to ferrous or brass connections.
9. The use of 50 - 50 solder for refrigeration piping is not recommended.
10. All tubing entrance holes must be properly sealed on the inside and outside of the cabinet before start up.

NEVER pipe suction and liquid lines from one system thru refrigerated areas of other systems.

NEVER direct a torch flame against the body of the cabinet. When brazing tubing, direct the torch flame away from the body of the cabinet, use a heat shield to protect the cabinet. The insulation will melt if exposed to high temperatures.

NEVER use the compressor as an evacuation pump. It is important that upon completion of the installation of the suction and liquid lines that the entire system be evacuated with a proper vacuum pump. Never use the compressor for this purpose and always evacuate the complete system in accordance with approved methods and procedures.

## **CHECK-LIST FOR USE BEFORE START-UP**

The following items should be checked when applicable to these cabinets:

Make sure that the gaskets at the joints of all cabinets make a proper seal between the cabinets.

Make sure that all fan motors are properly plugged in.

Make sure that all fan blades are tight on all fan motor shafts.

Make sure that the expansion valve sensing bulb is properly positioned and is tightly secured.

Make sure that tubing entrance holes both inside and outside the cabinet are properly sealed.

Make sure that all SEALANT MATERIAL that was removed from position in the cabinet during installation and piping is correctly replaced and seals in a satisfactory manner.

Make sure that all the loose debris in the cabinet that might plug the drain is removed.

Make sure the interior bottom pans are properly positioned.

Make sure that external drain traps will not become frozen by contact with suction lines.

## **Start-Up**

1. Electrically energize the cabinet. Check the supply voltage, must be within +/- 5%. Check the evaporator fan motors to ensure all are operating and rotating in the correct direction.

2. Electrically energize the refrigeration system. Check the supply voltage, must be within +/- 5%. Check the Thermostatic Expansion Valve Setting (as outlined in the Thermostatic Expansion Valve Setting section below), and adjust if necessary.

3. Set and check the Digital controller settings for cabinet temperature and defrost period. (as outlined in the Digital Control section below).

## **Thermostatic Expansion Valve Setting**

The expansion valve is located at the left end of the evaporator. The valve must be adjusted so that the coil is fully flooded, this will result in a superheat setting of approximately 5°F at the expansion valve sensing bulb.

## **ELECTRONIC DIGITAL CONTROLLER TEMPERATURE & DEFROST**

This cooler employs an Electronic Controller which controls the cabinets' temperature and defrosts period.



### **Temperature Control - Electronic**

The control is programmed to cycle based on discharge air temperature between 30°F to 40°F. The sensor for the control is located in Top Discharge Jet on the left side attached to the flue ceiling. The controller is located on the front center of the machine compartment base. The display on the controller is indicating the temperature at the Top Discharge Jet in the flue.

### **Warning**

This control has been calibrated and set at the factory to maintain the proper temperature. Before attempting to change this setting, the cabinet should be put into operation for a minimum of 16 hours.

If needed to change the setting of the controller follow these steps:

1. Push the [SET] key on the controller for more than 2 seconds to change Set point value.
2. The value of the set point will be displayed and the °F LED starts blinking.
3. To change the set value, push the [UP] or [DOWN] arrow to raise or lower set point.
4. To confirm the new set point value, push the [SET].

Once the control has been reset, allow the cabinet to run for 4 hours to stabilize.

### **Defrost Controller - Electronic**

The cabinet goes into defrost every 4 hours. From the initial start up. If you want to set the defrost period to start during closing hours simply push the [MELTING SNOW FLAKE] key for more than 2 seconds and a manual defrost will start. Now the next defrost will be 4 hours from that point. Defrost will terminate based on the evaporator coil temperature. The sensor to terminate defrost period is located in the evaporator coil on the left side, rear of the cabinet. When the coil temperature reaches 45°F the defrost period will terminate. Remember the Defrost Termination Temperature setting must be high enough to allow the coil to completely clear itself of frost and ice during the off cycle.

### **Loading Procedures**

When loading the cabinet, product should be pre-cooled. Do not load cabinet beyond shelf size limits; this will disturb the air curtain designed to keep the product cool. Do not allow any of the products to obstruct the return air grille, this will have a negative effect on the cabinet's cooling capability.

### **Maintenance Suggestions**

An attractive operation can be a very profitable. Dirty and poorly merchandised cabinets are offensive to most discriminating customers, so a clean attractive cabinet will pay dividends. Weekly or more often, if necessary, the display area should be cleaned and attractively stocked.

### **Important Notice**

1. ALWAYS disconnect the power to the cabinet before attempting to clean it with any liquid.
2. NEVER under any circumstances should a water hose be sprayed into this cabinet.
3. NEVER use ammonia or solutions with ammonia on this cabinet.
4. The use of abrasive cleaning materials on this cabinet will VOID all cabinet warranties.




## The Cleaning Process

1. Turn the power off from the source.
2. Remove all merchandise from the cabinet and store in a refrigerated area. Then remove all shelves and floor pans.
3. This cabinet can be hand cleaned internally with a mild soap detergent and hot water. Diluted non-chlorine bleach and hot water is a good sanitizer. The cleaning cloth should be just wet enough to get a reasonable cleaning action but should not be wet to a point where it will emit a large amount of water which will flow through the drain system causing it to overflow.
4. After the cabinet is cleaned, any remaining water in the cabinet can be soaked up with the use of a sponge and dried out with a dry cloth completely before resuming operations.
5. Make sure that the internal drain is open and remove all scraps, paper, and lint.
6. All external panels may be cleaned with a damp cloth, and then they may be polished with a dry lint free cloth. This will preserve the luster of the cabinet.

## Cleaning the Condenser

It is crucial that the condenser face be cleaned weekly. Due to the condensing unit's location near the floor, the condenser will quickly accumulate any dust or dirt from the location. A dirty condenser will diminish the cooling ability of the system, thus resulting in longer operational times and warmer product temperatures.

The condenser face can be cleaned with the use of a hose/brush attachment on a vacuum cleaner. Take care to avoid bending the condenser fins, It is of vital importance that the condenser gets the proper amount of air through the fins and around the tubes, therefore all dirt, lint, and dust needs to be removed



## Cleaning the Machine Compartment

At intervals of four to six months, or before if necessary, it is recommended that the Machine Compartment be cleaned out. It should be accomplished in the following order:

1. Shut down the cabinet electrically.
2. Remove the base grilles. Using a hose/brush attachment on a vacuum cleaner, all dirt, store lint and dust can be removed from the machine compartment.
3. If any traces of oil are found contact your Refrigeration Service person as soon as possible.
4. Before reloading the cabinet with merchandise, allow an hour for refrigeration pull-down. Make sure that all merchandise is in a good salable and refrigerated condition when reloading the cabinet.

## Trouble Chart

### A. Compressor will not start - no hum

#### Possible Causes:

1. Disconnect switch open
2. Blown fuse
3. Defective wiring
4. Overload protector tripped
5. Open control contacts (control may be defective, or unit location may be too cold)
6. Defective overload protector

### B. Compressor will not start - hums but cycles on overload

#### Possible Causes:

1. Low voltage
2. Unit wired incorrectly
3. Starting capacitor defective
4. Starting relay contact not closing
5. Compressor motor defective
6. High head pressure
7. Bearings on pistons tight - low oil charge

### C. Compressor starts, but starting winding remains in circuit

#### Possible Causes:

1. Low voltage
2. Unit wired incorrectly
3. Starting capacitor weak
4. Running capacitor defective
5. Starting relay defective
6. Compressor motor defective
7. High head pressure

### D. Compressor starts and runs but cycles on overload

#### Possible Causes:

1. Low voltage
2. Running capacitor defective
3. Overload protector defective
4. High head pressure
5. Fan motor, pump, etc., wired to wrong side of overload protector
6. Compressor motor partially grounded
7. Unbalanced line voltage (3 phase models)
8. Bearing or pistons tight - low oil charge

### E. Compressor short cycles

#### Possible Causes:

1. Control differential set too close
2. Refrigerant undercharge
3. Refrigerant overcharge
4. Discharge valve leaking
5. Expansion valve leaking
6. Cutting out on high pressure control
7. Cutting out on overload protector because of tight bearings, stuck piston, high head pressure or restricted air cooled condenser

### F. Compressor tries to start when electronic controller closes but cuts out on overload, starts after several attempts

#### Possible Causes:

1. Low voltage
2. Thermostat differential too close (lower than 4°)
3. Controller sensor may need to be checked, and is securely mounted.

### G. Running cycle too long, or unit operated continuously

#### Possible Causes:

1. Insufficient refrigerant charge
2. Dirty or restricted condenser
3. Unit: location too hot
4. Control contacts stuck
5. Air or other non-condensable gases in system
6. Expansion valve plugged or defective
7. Insufficient, defective or water - logged insulation
8. Evaporator coil plugged with ice or dirt

### H. Evaporator temperature too high

#### Possible Causes:

1. Shortage of refrigerant, or leak on system
2. Restricted filter drier
3. Control setting too high
4. Expansion valve restricted
5. Expansion valve too small
6. Evaporator coil plugged with ice or dirt
7. Evaporator oil logged

### I. Noisy Unit

#### Possible Causes:

1. Compressor oil charge low
2. Fan blade bent causing vibration
3. Fan motor bearings loose or worn
4. Tube rattle
5. Loose parts on condensing unit

### J. Liquid line hot

#### Possible Causes:

1. Unit undercharged or leak in system
2. Expansion valve opened too far
3. Condenser coil needs to be cleaned.

### K. Liquid line frosted

#### Possible Causes:

1. Restriction in filter drier
2. Shut off valve on receiver either partially closed or restricted

### L. Suction line sweating or frosted

#### Possible Causes:

1. Expansion valve open too wide
2. Evaporator iced up
3. Evaporator fan motors not operating

# Howard - McCray

## Parts List

### Refrigeration Components

<u>Part #</u>	<u>Description</u>	<u>Usage</u>
1SH6521	Evaporator Fan Assembly	6 Required
21-376-XR40CX	Digital Controller XR40CX	1 Required
51-240-ERVE10C	Expansion Valve (1 Ton R448A)	1 Required ( 5 FT )
51-240-ERVE15C	Expansion Valve ( 1 ½ Ton R448A)	1 Required ( 7 FT )
71-087	Condensing Unit ( 1 1/2hp R448A)	5 FT Self Contained
71-085	Condensing Unit (1-3/4hp R448A)	7 FT Self Contained
21-307-38	Solenoid Valve	Remote Models
21-330-1440	Condensate Pan 1440W@120V	Optional
20-452	Contactors 115V	1 Required
21-160	Power Switch	1 Required

### Canopy Light Components

<u>Part #</u>	<u>Description</u>	<u>Usage</u>
21-387-PS060	60w 24v LED DRIVER	1 for (7ft)
21-400-23	23" LED LIGHT STRIP	2 for (5ft) 2 for (7ft)
21-400-40	40" LED LIGHT STRIP	2 for (5ft)
21-400-62	62" LED LIGHT STRIP	2 for (7ft)
21-400-PW-120	120" POWER CORD	1 for (5ft) 1 for (7ft)

### Shelf Components

<u>Part #</u>	<u>Description</u>	<u>Usage</u>
21-387-PS100	100W 24V LED DRIVER	1 for (5ft) 1 for (7ft)
21-400-07	7" LED LIGHT STRIP	12 for (5ft) 12 for (7ft)
21-400-23	23" LED LIGHT STRIP	6 for (5ft)
21-400-45	45" LED LIGHT STRIP	6 for (7ft)
21-400-PW-120	120" Power Cord	6 for (5ft) 6 for (7ft)
41-030-8-LH	Shelf Brackets – 8" Left Hand	6 (5FT) 12 (7FT)
41-030-8-RH	Shelf Brackets – 8" Right Hand	6 (5FT) 12 (7FT)
41-030-6-LH	Shelf Brackets – 6" Left Hand	6 (5FT)
41-030-6-RH	Shelf Brackets – 6" Right Hand	6 (5FT)
5G1502-RADII	Shelf 8" Assembly	6 Required (5FT)
7G1502-RADII	Shelf 8" Assembly	6 Required (7FT)
30-639-X	Tab Moulding X = Length	Length Varies

### Grille Assemblies

<u>Part #</u>	<u>Description</u>	<u>Usage</u>
5G7763	Front Grille - White	1 Required (5FT)
5G7763-B	Front Grille - Black	1 Required (5FT)
5G7763-SS	Front Grille – Stainless Steel	1 Required (5FT)
7G7763	Front & Rear Grille – White	4 Required (7FT)
7G7763-B	Front & Rear Grille – Black	4 Required (7FT)
7G7763-SS	Front & Rear Grille – Stainless Steel	4 Required (7FT)
5G7764	Rear Grille – White	1 Required (5FT)
5G7764-B	Rear Grille – Black	1 Required (5FT)
5G7764-SS	Rear Grille – Stainless Steel	1 Required (5FT)

### Grille End

<u>Part #</u>	<u>Description</u>	<u>Usage</u>
7G4500-B	Grill – Motor End Panel - Black	2 Required
7G4500-W	Grill – Motor End Panel - White	2 Required

# Howard - McCray

## **Discharge Jet**

<b><u>Part #</u></b>	<b><u>Description</u></b>	<b><u>Usage</u></b>
5G4501	Front & Rear Discharge - White	2 Required
7G4501	Front & Rear Discharge - White	2 Required
5G4501-B	Front & Rear Discharge - Black	2 Required
7G4501-B	Front & Rear Discharge - Black	2 Required
7G4502	End Discharge	2 Required
7G4502-B	End Discharge	2 Required

## **Product Stops and Rail**

<b><u>Part #</u></b>	<b><u>Description</u></b>	<b><u>Usage</u></b>
30-743	Front & Rear Product Stop	2 Required (5FT)
30-733	Front & Rear Product Stop	2 Required (7FT)
30-734	Side Product Stop	2 Required
31-567-500	Curve Front Rail Plexiglas	4 Required (5FT)
31-559-500	Curve Front Rail Plexiglas	4 Required (7FT)

**NOTE:** Additional parts not included in this list are available from the factory. Contact the Parts & Service department at the phone numbers at the bottom of the page.



## Keep this Page for Your Records:

Dear Customer:

We wish to congratulate you on your judgment. We are very proud to have been privileged to serve you with Howard-McCray equipment to fill your requirements.

Howard-McCray equipment is the product of a company dedicated in producing products of quality, incorporating progressive features on a timely basis and backed by a warranty which provides confidence.

Should you have any questions regarding features, operation, or service, call the Howard-McCray Assistance Center toll free. (800-344-8222)

Thank you,

Howard-McCray

### **Customer Installation Record:**

Cabinet Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

Condensing Unit Model Number and Horsepower \_\_\_\_\_

Type of Control \_\_\_\_\_

Refrigerant \_\_\_\_\_

Thermostat \_\_\_\_\_

Other \_\_\_\_\_

\_\_\_\_\_

Defrost Period \_\_\_\_\_

Date of Start-Up \_\_\_\_\_

Other Remarks \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Installing Contractor \_\_\_\_\_

\_\_\_\_\_

Address \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

Phone Number \_\_\_\_\_

# Howard - McGray

**NOTES:**

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.





## **Commercial Warranty**

This warranty applies to all shipments made from HMC Enterprises LLC – known as Howard/McCray or “McCray” after 1/1/24 **Customers must obtain a service authorization number (SA) for ALL WARRANTY CLAIMS.**

### **ONE YEAR PARTS & LABOR WARRANTY**

McCray warrants to the original purchaser of every new McCray refrigerated unit, the cabinet and all parts thereof, to be free from defects in material workmanship, under normal and proper use and ROUTINE Maintenance as specified by McCray and upon proper installation and start up by a commercially qualified refrigeration company in accordance with the instruction packet supplied with each McCray unit. McCray's obligation under this warranty is limited to a period on one (1) year from date of original installation or 15 months after shipment from McCray, whichever comes first.

Any parts covered under this warranty that are determined by McCray to have been defective within ONE (1) year from date of installation or (15) months after shipment from McCray, whichever occurs first, is limited to the repair or replacement, including labor charges or defective parts or assemblies as outlined in the labor & parts Warranty Schedule

Warranty does not cover household use or normal wear & tear items such as gaskets, light bulbs & broken glass. Failure to register the unit in the warranty program will void the warranty. Failure to clean the condenser on a weekly basis will also void the warranty. Warranty does not cover issues caused by improper installation, lack of maintenance or effects of Mother Nature such as floods, lighting storms or other damaging situations.

### **5 YEAR COMPRESSOR WARRANTY**

In addition to the five (5) year warranty above, McCray warrants its compressors, hermetically & semi-hermetically sealed compressors to be free from defects in both material and workmanship under normal and proper use and maintenance service for a period of five (5) years from date of installation or five (5) years & three (3) months from date of shipment. Compressors found defective during the first fourteen (14) must be returned to the Authorized Refrigeration Supply Company for an exchange. If the compressor is over fourteen (14) months, McCray “Reserves the Right” to exchange or replace the compressor with a compressor of similar age. After two (2) years, compressor replacements will be prorated based on the remaining age of the compressor. See our Warranty Schedule for full details. The five year warranty only applies to the compressor and no other parts even those related to the compressor. FAILURE to CLEAN the condenser routinely will void this warranty

### **WARRANTY CLAIMS**

McCray's sole obligation under this warranty is limited to either repair or replacement of parts, subject to the additional limitations below. This warranty neither assumes nor authorizes any person to assume obligations other than those expressly covered by this warranty. This is a commercial warranty and does cover use in a non commercial establishment



## **WHAT IS NOT COVERED BY THIS WARRANTY**

Damaged goods are not to be returned to the factory. Claims for damages must be made by the consignee with the carrier. Howard/McCray assumes no responsibility for damage while in transit.

## **NON-CONSEQUENTIAL DAMAGES**

McCray is not responsible for economic loss, profit loss or special, indirect or consequential damages, including without limitation, losses or damages arising from food or product spoilage claims, whether or not, they were caused by refrigeration failure.

## **WARRANTY IS NOT TRANSFERABLE**

This warranty is not assignable and applies only in favor of the original purchaser/user to whom the product was delivered. Any such assignment or transfer shall void the warranties herein made and shall void all warranties, express or implied, including any warranty of merchantability or fitness for a particular purpose.

## **IMPROPER USE**

McCray assumes no liability for parts or labor coverage for component failure or damages resulting from usage, installation or failure to clean and/or maintain as set forth in the warranty packet provided with the unit. Condensing coils **MUST BE CLEANED WEEKLY**.

## **ALTERATION, NEGLIGENCE, ABUSE, MISUSE, ACCIDENT, DAMAGE DURING TRANSIT OR INSTALLATION, FIRE, FLOOD OR OTHER ACTS OF GOD**

McCray is not responsible for the repair or replacement of any parts McCray determines have been subjected after date of manufacture to alteration, neglect, abuse, misuse, accident, damage during transit or installation, fire, flood or acts of God.

## **IMPROPER ELECTRICAL CONNECTIONS**

McCray is not responsible for repair or replacement of failed or damaged components resulting from electrical power failure, the use of extension cords, low voltage or voltage drops or spikes to the unit.

## **NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE**

There are **NO OTHER WARRANTIES**, expressed, implied or statutory, except the one (1) year parts and labor and five (5) year compressor warranty as described above. These warranties are exclusive and in lieu of all other warranties, including implied warranty and merchantability or fitness for a particular purpose. There are no warranties which extend beyond the description on the face hereof

## **OUTSIDE U.S.**

This warranty does not apply to and McCray is not responsible for, any warranty claims made on products sold or used outside the United States.

Technical Service call at 1-800-344-8222 or email at [techservice@howardmccray.com](mailto:techservice@howardmccray.com).

## **Limited Warranty Guidelines**

Issued 01/01/2024

The warranty does not cover product loss or consequential damages.  
TO ACTIVATE THE WARRANTY, THE FOLLOWING MUST BE COMPLETE:

1. Payment in full to Howard McCray.
2. Installed by a Qualified Refrigeration Company (1)

Warranty includes, but is not limited to, Refrigerators, Freezers and display cases sold in the Continental United States to the original Dealer and the respective customer. The warranty must be activated before any claims can be processed. This warranty cannot be transferred under any circumstances. Howard McCray products are made for commercial use only, any warranty claim for residential use will be denied and void immediately.

(1) A Qualified Refrigeration Company is defined as a fully licensed and insured refrigeration company that handles food service equipment.

### **Warranty for Self Contained Equipment:**

Compressor - 1 Year from Date of Installation or 15 Months from Date of Shipment, whichever comes first.

Parts - 1 Year from Date of Installation or 15 Months from Date of Shipment, whichever comes first.

Labor - 90 Calendar days from Date of Installation or 120 days from Date of Shipment, whichever comes first.

### **Extended Warranty for Self Contained Equipment**

Compressor - 4 additional years - 5 years from date of installation or 5 years 3 months from Date of Shipment - whichever comes first. Compressor age will be prorated according to Schedule A. - COMPRESSORS

### **Warranty for Remote Cases**

The above Labor & Parts warranty apply to Remote units, for items that are installed by the factory (Howard McCray). Expansion valves and related components involved in the installation of these units is not covered nor any part affected by the installation. Refrigerant loss is not covered.

**FAILURE TO CLEAN THE CONDENSER  
WEEKLY WILL VOID THE FACTORY  
WARRANTY**

**All Warranty Claims must include the following or they will not be processed. The required is:**

1. Service Authorization Number (SA#) – Provided by Howard McCray
2. Date of service
3. Model number of unit being serviced
4. Serial number of unit being serviced
5. Copy of wholesaler receipt for all parts replaced including compressor.

**Please fill out Request for Warranty Reimbursement Form – Schedule D**

**The Recommended Service Allowances by HMC is listed on Schedule B**

## **ITEMS NOT COVERED BY WARRANTY**

**Product Loss**

**Expansion Valves on Remote units**

**Light bulbs of any type except LED – See Schedule C**

**Adjustments of any type including thermostats, time clocks, expansion valves, hinges or controls - electronic or manual**

**Broken or cracked glass**

**Improper installation**

**Electrical surges which cause components to burn out**

**Damages due to spraying water into the unit**

**Claims not submitted within 60 days of date of service**

**Equipment that has experienced other stress or hazards such as floods, fire or other acts of nature.**

**One call per unit per problem**

**All Howard McCray equipment is intended for indoor use with ambient temperatures not exceeding 75 degrees and 55% relative humidity.**



## SCHEDULE A – COMPRESSOR REPLACEMENTS

FAILURE TO CLEAN THE CONDENSOR COIL ON A WEEKLY BASIS WILL VOID THE WARRANTY

First 15 months the compressor must be exchanged at the local refrigeration wholesaler.

The Factory reserves the right to supply the replacement compressor if the compressor is older than 16 months.

Months 16-36 - 100% reimbursement from factory provided the factory is provided the Compressor plate (photo will be permitted) and copy of actual invoice from the local refrigeration wholesaler.

Months 37-48 - 75% reimbursement from factory provided the factory is provided the compressor plate (photo will be permitted) and copy of actual invoice from the local refrigeration wholesaler.

Months 49-60 - 50% reimbursement from factory provided the factory is provided the compressor plate (photo will be permitted) and a copy of the actual invoice from the local refrigeration wholesaler.

FAILURE TO CLEAN THE CONDENSOR COIL ON A WEEKLY BASIS WILL VOID THE WARRANTY

## SCHEDULE B – LABOR RATES

	<u>Allowable Labor hours</u>	<u>Part must be returned</u>
<u>Item</u>	<u>Allowable</u>	<u>Part</u>
<u>REPAIR MATERIAL/TOOLS NOT EXCEED \$200.00</u>		
Compressor Replacement	4.0	Exchange
Compressor components	1.0	No
Replace Evaporator Coil	4.0	Yes
Replace Expansion valve	2.5	Yes
Replace Evaporator fan motor	1.0	Yes
Replace Condenser Fan Motor	2.0	Exchange
Replace High pressure switch	2.0	Yes
Diagnose & repair refrigerant leak, replace sight glass & drier	2.5	No
<u>Electrical Components</u>		
Diagnose and repair light switch	1.0	Yes
Diagnose and repair LED Driver	1.0	Yes
Diagnose and repair electronic controller	2.0	Yes
Diagnose and repair electronic controller sensor	1.0	No
Diagnose and repair Condensate pan	1.0	Yes

Sight glass reimbursement total = \$40.00

Filter drier reimbursement total = \$40.00

Travel time - Not to exceed 1.5 hour's max  
charge is \$180.00

Labor hours - Overtime is not permitted

Reclaim fee - Maximum allowance is \$  
50.00 Allowances





## **SCHEDULE C - PARTS WARRANTY**

Some Parts are covered by 1 year Original factory warranty. These parts will be replaced by the original factory supplying these parts or a designated wholesaler as listed.

Glass doors on RIF,RIN,GR or GF series are covered by Anthony International. Claims must contain Anthony Work order number

Hot Wells are covered by APW and all claims must contain APW serial number

Outdoor Condensing units are covered by the refrigeration company supplying the condensing units. These claims must include the condensing unit serial number.

Compressor Components including starter components, relays, condensing fan motors and other related components must be exchanged at the local refrigeration wholesaler within 12 months of date of service or 15 months from factory shipment.

Refrigerant – only the factory specified charge amount will be accepted. The charges are listed on the serial plate. The current Refrigerant rate is \$ 20.00 per LB

Electronics Controls must be returned to factory for reimbursement.

LED lights & drivers (ballast) must be returned to factory for reimbursement.

It is the responsibility of the repairing refrigeration company to return these parts to HMC in order for the claim to be processed. The part must be MARKED with:

Service Authorization # (SA#)

Model#

Serial #

**All reimbursement requests for parts must include wholesaler invoice copy.**



## Request for Warranty Reimbursement – Schedule D

Howard/McCray  
HMC Enterprises LLC  
831 E. Cayuga St  
Philadelphia, PA 19124

For questions related to Warranty & Service  
for Technical Service  
TSC@howardmccray.com

Today's Date \_\_\_\_\_ Date of Service \_\_\_\_\_

Service Authorization Number (SA#) \_\_\_\_\_

Model Number \_\_\_\_\_

Serial Number \_\_\_\_\_

Service Company \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ State/Province \_\_\_\_\_

Zip Code \_\_\_\_\_ Contact Phone Number \_\_\_\_\_

Email Address \_\_\_\_\_

Service Performed \_\_\_\_\_

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Labor Rate per hour \_\_\_\_\_ Labor Hours to perform service \_\_\_\_\_

Travel Time \_\_\_\_\_

### Checklist

Copy of refrigeration wholesaler invoices for all parts used \_\_\_\_\_

Original Service invoice from your company \_\_\_\_\_

Copy or Photo of Compressor Tag \_\_\_\_\_

Service Authorization on all documents \_\_\_\_\_

Name & Contact Number \_\_\_\_\_

## Control Factory (F-C) Settings February 11, 2014 21-376-XR40CX

Label	Set-F	Set-C	Label	Name	Set-F	Set-C
Set	30	-1.1	dAF	Defrost delay after fast freez	0.0	0.0
Hy	10	5.5	ALC	Temp. alarm configuration	ab	ab
LS	20	-6	ALU	MAX temperature alarm	45	8
US	45	8	ALL	MIN. temperature alarm	20	-6
Ot	0	0	AFH	Diff for temp. alarm recovery	10	5
P2P	y	y	ALd	Temp. alarm delay	60	60
OE	0	0	DAO	Delay of temp alarm at start up	2.0	2.0
P3P	n	n	AP2	Probe for temp. alarm of cond	P4	P4
O3	0	0	AL2	Cond for low temp alarm	-40	-40
P4P	n	n	AU2	Cond for high temp alarm	230	230
O4	0	0	AH2	Diff for cond. Temp alarm rec	10	10
OdS	1	1	Ad2	Cond temp alarm delay	15	15
AC	1	1	dA2	Delay of cond temp alarm start up	1.3	1.3
rtr	100	100	bLL	Comp off for cond low temp alarm	n	n
CCt	0.0	0.0	AC2	Comp off for cond high temp alarm	n	n
CCS	0	0	i1P	Digital input polarity	cL	cL
COOn	12	12	i1F	Digital input configuration	EAL	EAL
COF	8	8	did	Digital input alarm delay	5	5
CF	F	C	Nps	Number of act of pressure switch	15	15
rES	in	de	odc	Compress status when open dr	no	no
Lod	P1	P1	rrd	Regulation restart with DR open alarm	y	y
dLy	0.0	0.0	HES	Differential for energy saving	0	0
dtr	50	50	Adr	Serial address	1	1
tdIF	EL	EL	PbC	Kind of probe	ntc	ntc
dFP	P2	P2	onF	on/off key enabling	no	no
dIE	45	7.2	dP1	Room probe display	--	--
IdF	4	4	dP2	Evaporator probe display	--	--
NdF	60	60	dP3	Third probe display	nop	nop
dSd	0	0	dP4	Fourth probe display	nop	nop
dFd	rt	rt	rSE	Valore set operativo	--	--
dAd	0	0	rEL	Software release	1.0	1.0
Fdt	0	0	Ptb	Map code	7	7
dPO	n	n	BOLD	Pr2		
TO SEE SET POINT TEMPERATURE, PRESS SET KEY AND RELEASE TO DISPLAY SET POINT						
OD421-7 Open Series Settings						
DEF-BUTTON = P2 DISPLAY						



## Digital controller with defrost management XR40CX

### CONTENTS

1. GENERAL WARNING	1
2. GENERAL DESCRIPTION	1
3. CONTROLLING LOADS	1
4. FRONT PANEL COMMANDS	1
5. MAX & MIN TEMPERATURE MEMORIZATION	1
6. MAIN FUNCTIONS	1
7. PARAMETERS	2
8. DIGITAL INPUT (ENABLED WITH P3P = N)	3
9. TTL SERIAL LINE - FOR MONITORING SYSTEMS	3
10. X-REP OUTPUT - OPTIONAL	3
11. INSTALLATION AND MOUNTING	3
12. ELECTRICAL CONNECTIONS	3
13. HOW TO USE THE HOT KEY	3
14. ALARM SIGNALS	3
15. TECHNICAL DATA	3
16. CONNECTIONS	4
17. DEFAULT SETTING VALUES	4

## 1. GENERAL WARNING

### 1.1 PLEASE READ BEFORE USING THIS MANUAL

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.

### 1.2 SAFETY PRECAUTIONS

- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation.
- Warning: disconnect all electrical connections before any kind of maintenance.
- Fit the probe where it is not accessible by the End User. The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "Dixell S.p.A." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

## 2. GENERAL DESCRIPTION

Model **XR40CX**, format 32 x 74 mm, is microprocessor based controller, suitable for applications on medium or low temperature refrigerating units. It has 2 relay outputs to control compressor and defrost, which can be either electrical or reverse cycle (hot gas). It is also provided with three NTC or PTC probe inputs, the first one for temperature control, the second one, to be located onto the evaporator, to control the defrost termination temperature, the third one, optional, to connect to the HOT KEY terminals to signal the condenser temperature alarm or to display a temperature. The digital input can operate as fourth temperature probe.


The HOT KEY output allows to connect the unit, by means of the external module XJ485-CX, to a network line ModBUS-RTU compatible such as the **dxell** monitoring units of X-WEB family. It allows to program the controller by means of the HOT KEY programming keyboard.

The instrument is fully configurable through special parameters that can be easily programmed through the keyboard.

## 3. CONTROLLING LOADS

### 3.1 COMPRESSOR

The regulation is performed according to the temperature measured by the thermostat probe with a positive differential from the set point: if the temperature increases and reaches set point plus differential the compressor is started and then turned off when the temperature reaches the set point value again.



In case of fault in the thermostat probe the start and stop of the compressor are timed through parameters "CON" and "COF".

### 3.2 DEFROST

Two defrost modes are available through the "tdF" parameter: defrost through electrical heater (tdF = EL) and hot gas defrost (tdF = in). Other parameters are used to control the interval between defrost cycles (IdF), its maximum length (MdF) and two defrost modes: timed or controlled by the evaporator's probe (P2P).

At the end of defrost dripping time is started, its length is set in the FSt parameter. With FSt=0 the dripping time is disabled.

## 4. FRONT PANEL COMMANDS



**SET**: To display target set point; in programming mode it selects a parameter or confirm an operation.

**⚙ (DEF)** To start a manual defrost

**⬆ (UP)**: To see the max. stored temperature; in programming mode it browses the parameter codes or increases the displayed value.

**⬇ (DOWN)**: To see the min stored temperature; in programming mode it browses the parameter codes or decreases the displayed value.

**⏻** To switch the instrument off, if onF = oFF.

**☀** Not enabled.

### KEY COMBINATIONS:

**⬆ + ⬇** To lock & unlock the keyboard.

**SET + ⬇** To enter in programming mode.

**SET + ⬆** To return to the room temperature display.

## 4.1 USE OF LEDS

Each LED function is described in the following table.

LED	MODE	FUNCTION
☀	ON	Compressor enabled
☀	Flashing	Anti-short cycle delay enabled
☀	ON	Defrost enabled
☀	Flashing	Drip time in progress
⚠	ON	An alarm is occurring
⚠	ON	Continuous cycle is running
⚠	ON	Energy saving enabled
°C°	ON	Measurement unit
°C°	Flashing	Programming phase

## 5. MAX & MIN TEMPERATURE MEMORIZATION

### 5.1 HOW TO SEE THE MIN TEMPERATURE

- Press and release the **⬇** key.
- The "Lo" message will be displayed followed by the minimum temperature recorded.
- By pressing the **⬇** key again or by waiting 5s the normal display will be restored.

### 5.2 HOW TO SEE THE MAX TEMPERATURE

- Press and release the **⬆** key.
- The "Hi" message will be displayed followed by the maximum temperature recorded.
- By pressing the **⬆** key again or by waiting 5s the normal display will be restored.

### 5.3 HOW TO RESET THE MAX AND MIN TEMPERATURE RECORDED

- Hold press the SET key for more than 3s, while the max. or min temperature is displayed. (rSt message will be displayed)
- To confirm the operation the "rSt" message starts blinking and the normal temperature will be displayed.

## 6. MAIN FUNCTIONS

### 6.1 HOW TO SEE THE SETPOINT

- Push and immediately release the **SET** key; the display will show the Set point value;
- Push and immediately release the **SET** key or wait for 5 seconds to display the probe value again.

### 6.2 HOW TO CHANGE THE SETPOINT

- Push the **SET** key for more than 2 seconds to change the Set point value;
- The value of the set point will be displayed and the "°C" or "°F" LED starts blinking.
- To change the Set value push the **⬆** or **⬇** arrows within 10s.
- To memorise the new set point value push the **SET** key again or wait 10s.

### 6.3 HOW TO START A MANUAL DEFROST

- Push the **DEF** key for more than 2 seconds and a manual defrost will start.

### 6.4 HOW TO CHANGE A PARAMETER VALUE

To change the parameter's value operate as follows:



1. Enter the Programming mode by pressing the **Set** + **▼** keys for 3s (the "°C" or "°F" LED starts blinking).
  2. Select the required parameter. Press the "SET" key to display its value.
  3. Use "UP" or "DOWN" to change its value.
  4. Press "SET" to store the new value and move to the following parameter.
- To exit:** Press **SET** + **UP** or wait 15s without pressing a key.
- NOTE:** the set value is stored even when the procedure is exited by waiting the time-out to expire.

### 6.5 THE HIDDEN MENU

The hidden menu includes all the parameters of the instrument.

#### 6.5.1 HOW TO ENTER THE HIDDEN MENU

1. Enter the Programming mode by pressing the **Set** + **▼** keys for 3s (the "°C" or "°F" LED starts blinking).
  2. Released the keys, then push again the **Set** + **▼** keys for more than 7s. The Pr2 label will be displayed immediately followed from the HY parameter.
- NOW YOU ARE IN THE HIDDEN MENU.**
3. Select the required parameter.
  4. Press the "SET" key to display its value.
  5. Use **▲** or **▼** to change its value.
  6. Press "SET" to store the new value and move to the following parameter.
- To exit:** Press **SET** + **▲** or wait 15s without pressing a key.
- NOTE1:** if none parameter is present in Pr1, after 3s the "noPr" message is displayed. Keep the keys pushed till the Pr2 message is displayed.
- NOTE2:** the set value is stored even when the procedure is exited by waiting the time-out to expire.

#### 6.5.2 HOW TO MOVE A PARAMETER FROM THE HIDDEN MENU TO THE FIRST LEVEL AND VICEVERSA.

Each parameter present in the HIDDEN MENU can be removed or put into "THE FIRST LEVEL" (user level) by pressing "SET" + **▼**.

In HIDDEN MENU when a parameter is present in First Level the decimal point is on.

### 6.6 HOW TO LOCK THE KEYBOARD

1. Keep pressed for more than 3 s the **UP** + **DOWN** keys.
2. The "POF" message will be displayed and the keyboard will be locked. At this point it will be possible only to see the set point or the MAX o Min temperature stored.
3. If a key is pressed more than 3s the "POF" message will be displayed.

### 6.7 TO UNLOCK THE KEYBOARD

Keep pressed together for more than 3s the **▲** and **▼** keys, till the "Pon" message will be displayed.

### 6.8 THE CONTINUOUS CYCLE

When defrost is not in progress, it can be activated by holding the "▲" key pressed for about 3 seconds. The compressor operates to maintain the "ccS" set point for the time set through the "CCt" parameter. The cycle can be terminated before the end of the set time using the same activation key "▲" for 3 seconds.

### 6.9 THE ON/OFF FUNCTION

With "onF = oFF", pushing the ON/OFF key, the instrument is switched off. The "OFF" message is displayed. In this configuration, the regulation is disabled.

To switch the instrument on, push again the ON/OFF key.

**WARNING:** Loads connected to the normally closed contacts of the relays are always supplied and under voltage, even if the instrument is in stand by mode.

## 7. PARAMETERS

### REGULATION

**Hy Differential:** (0,1 + 25,5°C / 1-255 °F) Intervention differential for set point. Compressor Cut IN is Set Point + differential (Hy). Compressor Cut OUT is when the temperature reaches the set point.

**LS Minimum set point:** (-50°C/-SET/58°F-SET). Sets the minimum value for the set point.

**US Maximum set point:** (SET-110°C/SET-230°F). Set the maximum value for set point.

**Ot Thermostat probe calibration:** (-12,0-12,0°C; -120-120°F) allows to adjust possible offset of the thermostat probe.

**P2P Evaporator probe presence:** n= not present; the defrost stops by time; y= present; the defrost stops by temperature.

**OE Evaporator probe calibration:** (-12,0-12,0°C; -120-120°F). allows to adjust possible offset of the evaporator probe.

**P3P Third probe presence (P3):** n= not present, the terminal operates as digital input; y= present, the terminal operates as third probe.

**O3 Third probe calibration (P3):** (-12,0-12,0°C; -120-120°F). allows to adjust possible offset of the third probe.

**P4P Fourth probe presence:** (n = Not present, y = present).

**o4 Fourth probe calibration:** (-12,0-12,0°C) allows to adjust possible offset of the fourth probe.

**oDS Outputs activation delay at start up:** (0-255min) This function is enabled at the initial start up of the instrument and inhibits any output activation for the period of time set in the parameter.

**AC Anti-short cycle delay:** (0-50 min) minimum interval between the compressor stop and the following restart.

**rtr Percentage of the second and first probe for regulation (0-100; 100 = P1, 0 = P2):** it allows to set the regulation according to the percentage of the first and second probe, as for the following formula (rtr(P1-P2)/100 + P2).

**CCt Compressor ON time during continuous cycle:** (0,0-24,0h; res. 10min) Allows to set the length of the continuous cycle: compressor stays on without interruption for the CCt time. Can be used, for instance, when the room is filled with new products.

**CCS Set point for continuous cycle:** (-50-150°C) it sets the set point used during the continuous cycle.

**COOn Compressor ON time with faulty probe:** (0-255 min) time during which the compressor is active in case of faulty thermostat probe. With COOn=0 compressor is always OFF.

**COF Compressor OFF time with faulty probe:** (0-255 min) time during which the compressor is OFF in case of faulty thermostat probe. With COF=0 compressor is always active.

### DISPLAY

**CF Temperature measurement unit:** °C=Celsius; °F=Fahrenheit. WARNING: When the measurement unit is changed the SET point and the values of the parameters Hy, LS, US, Ot, ALU and ALL have to be checked and modified if necessary.

**rES Resolution (for °C):** (in = 1°C; dE = 0.1 °C) allows decimal point display.

**Lod Instrument display:** (P1; P2, P3, P4, SET, dtr): it selects which probe is displayed by the instrument: P1 = Thermostat probe; P2 = Evaporator probe; P3 = Third probe (only for model with this option enabled); P4 = Fourth probe, SET = set point; dtr = percentage of visualization.

**rEd X- REP display (optional):** (P1; P2, P3, P4, SET, dtr): it selects which probe is displayed by X- REP: P1 = Thermostat probe; P2 = Evaporator probe; P3 = Third probe (only for model with this option enabled); P4 = Fourth probe, SET = set point; dtr = percentage of visualization.

**dLy Display delay:** (0 -20,0m; res. 10s) when the temperature increases, the display is updated of 1 °C/1°F after this time.

**dtr Percentage of the second and first probe for visualization when Lod = dtr (0-100; 100 = P1, 0 = P2):** if Lod = dtr it allows to set the visualization according to the percentage of the first and second probe, as for the following formula (dtr(P1-P2)/100 + P2).

### DEFROST

**dFP Probe selection for defrost termination:** nP = no probe; P1 = thermostat probe; P2 = evaporator probe; P3 = configurable probe; P4 = Probe on Hot Key plug.

**tdF Defrost type:** EL = electrical heater; in = hot gas.

**dTE Defrost termination temperature:** (-50-50 °C/-58-122°F) (Enabled only when EdF=Pb) sets the temperature measured by the evaporator probe, which causes the end of defrost.

**ldF Interval between defrost cycles:** (0-120h) Determines the time interval between the beginning of two defrost cycles.

**MdF (Maximum) length for defrost:** (0-255min) When P2P = n, (not evaporator probe: timed defrost) it sets the defrost duration, when P2P = y (defrost end based on temperature) it sets the maximum length for defrost.

**dSd Start defrost delay:** (0-99min) This is useful when different defrost start times are necessary to avoid overloading the plant.

**dFd Temperature displayed during defrost:** (rt = real temperature; It = temperature at defrost start; SET = set point; dEF = "dEF" label)

**dAd MAX display delay after defrost:** (0-255min). Sets the maximum time between the end of defrost and the restarting of the real room temperature display.

**Fdt Drip time:** (0-120 min) time interval between reaching defrost termination temperature and the restoring of the control's normal operation. This time allows the evaporator to eliminate water drops that might have formed due to defrost.

**dPo First defrost after start-up:** (y = immediately; n = after the ldF time)

**dAF Defrost delay after continuous cycle:** (0-23,5h) time interval between the end of the fast freezing cycle and the following defrost related to it.

### ALARMS

**ALC Temperature alarms configuration:** (Ab; rE)

Ab= absolute temperature: alarm temperature is given by the ALL or ALU values. rE = temperature alarms are referred to the set point. Temperature alarm is enabled when the temperature exceeds the "SET+ALL" or "SET-ALL" values.

**ALU MAXIMUM temperature alarm:** (SET-110°C; SET-230°F) when this temperature is reached the alarm is enabled, after the "ALd" delay time.

**ALL Minimum temperature alarm:** (-50,0 - SET°C; -58-230°F) when this temperature is reached the alarm is enabled, after the "ALd" delay time.

**AFH Differential for temperature alarm recovery:** (0,1-25,5°C; 1-45°F) Intervention differential for recovery of temperature alarm.

**ALd Temperature alarm delay:** (0-255 min) time interval between the detection of an alarm condition and alarm signalling.

**dAO Exclusion of temperature alarm at startup:** (from 0,0 min to 23,5h) time interval between the detection of the temperature alarm condition after instrument power on and alarm signalling.

### CONDENSER TEMPERATURE ALARM (detected by the fourth probe)

**AP2 Probe selection for temperature alarm of condenser:** nP = no probe; P1 = thermostat probe; P2 = evaporator probe; P3 = configurable probe; P4 = Probe on Hot Key plug.

**AL2 Low temperature alarm of condenser:** (-55-150°C) when this temperature is reached the LA2 alarm is signalled, possibly after the Ad2 delay.

**Au2 High temperature alarm of condenser:** (-55-150°C) when this temperature is reached the HA2 alarm is signalled, possibly after the Ad2 delay.

**AH2 Differential for temperature condenser alarm recovery:** (0,1-25,5°C; 1-45°F)

**Ad2 Condenser temperature alarm delay:** (0-255 min) time interval between the detection of the condenser alarm condition and alarm signalling.

**dA2 Condenser temperature alarm exclusion at start up:** (from 0,0 min to 23,5h; res. 10min)

**bLL Compressor off with low temperature alarm of condenser:** n = no: compressor keeps on working; Y = yes, compressor is switched off till the alarm is present, in any case regulation restarts after AC time at minimum.

**AC2 Compressor off with high temperature alarm of condenser:** n = no: compressor keeps on working; Y = yes, compressor is switched off till the alarm is present, in any case regulation restarts after AC time at minimum.

### DIGITAL INPUT

**i1P Digital input polarity:** oP: the digital input is activated by opening the contact; CL: the digital input is activated by closing the contact.

**i1F Digital input configuration:** EAL = external alarm: "EA" message is displayed; bAL = serious alarm "CA" message is displayed. PAL = pressure switch alarm, "CA" message is displayed; dor = door switch function; dEF = activation of a defrost cycle; AUS = not enabled; Htr = kind of action inversion (cooling - heating); Fan = not set it; ES = Energy saving.

**did:** (0-255 min) with i1F = EAL or i1F = bAL digital input alarm delay: delay between the detection of the external alarm condition and its signalling.

**with i1F = dor:** door open signalling delay

**with i1F = PAL:** time for pressure switch function: time interval to calculate the number of the pressure switch activation.

**nPS Pressure switch number:** (0-15) Number of activation of the pressure switch, during the "did" interval, before signalling the alarm event (i2F = PAL).

**If the nPS activation in the did time is reached, switch off and on the instrument to restart normal regulation.**

**ode Compressor status when open door:** no; Fan = normal; CP; F\_C = Compressor OFF.

**rrd Outputs restart after doA alarm:** no = outputs not affected by the doA alarm; yES = outputs restart with the doA alarm;



**HES Temperature increase during the Energy Saving cycle :** (-30,0°C-30,0°C/-22~86°F) it sets the increasing value of the set point during the Energy Saving cycle

#### OTHER

**Adr Serial address** (1-244): Identifies the instrument address when connected to a ModBUS compatible monitoring system.

**PbC Type of probe:** it allows to set the kind of probe used by the instrument: **PbC** = PBC probe, **ntc** = NTC probe.

**onF on/off key enabling:** **nu** = disabled; **off** = enabled; **ES** = not set it.

**dp1 Thermostat probe display**

**dp2 Evaporator probe display**

**dp3 Third probe display: optional**

**dp4 Fourth probe display**

**rSE Real set point:** (readable only), it shows the set point used during the energy saving cycle or during the continuous cycle.

**rEL Software release** for internal use.

**Ptb Parameter table code:** readable only.

### 8. DIGITAL INPUT (ENABLED WITH P3P = N)

The free voltage digital input is programmable in different configurations by the **"i1F"** parameter.

#### 8.1 DOOR SWITCH INPUT (i1F = dor)

It signals the door status and the corresponding relay output status through the **"ode"** parameter: **no**, **Fan** = normal (any change); **CPr**, **F\_C** = Compressor OFF.

Since the door is opened, after the delay time set through parameter **"did"**, the door alarm is enabled, the display shows the message **"dA"** and the regulation restarts is **rtr = yES**. The alarm stops as soon as the external digital input is disabled again. With the door open, the high and low temperature alarms are disabled.

#### 8.2 GENERIC ALARM (i1F = EAL)

As soon as the digital input is activated the unit will wait for **"did"** time delay before signalling the **"EAL"** alarm message. The outputs status don't change. The alarm stops just after the digital input is de-activated.

#### 8.3 SERIOUS ALARM MODE (i1F = bAL)

When the digital input is activated, the unit will wait for **"did"** delay before signalling the **"CA"** alarm message. The relay outputs are switched OFF. The alarm will stop as soon as the digital input is de-activated.

#### 8.4 PRESSURE SWITCH (i1F = PAL)

If during the interval time set by **"did"** parameter, the pressure switch has reached the number of activation of the **"nPS"** parameter, the **"CA"** pressure alarm message will be displayed. The compressor and the regulation are stopped. When the digital input is ON the compressor is always OFF.

If the **nPS** activation in the **did** time is reached, switch off and on the instrument to restart normal regulation.

#### 8.5 START DEFROST (i1F = dFr)

It starts a defrost if there are the right conditions. After the defrost is finished, the normal regulation will restart only if the digital input is disabled otherwise the instrument will wait until the **"Mdf"** safety time is expired.

#### 8.6 INVERSION OF THE KIND OF ACTION: HEATING-COOLING (i1F = Htr)

This function allows to invert the regulation of the controller: from cooling to heating and viceversa.

#### 8.7 ENERGY SAVING (i1F = ES)

The Energy Saving function allows to change the set point value as the result of the **SET+HES** (parameter) sum. This function is enabled until the digital input is activated.

#### 8.8 DIGITAL INPUTS POLARITY

The digital input polarity depends on the **"i1P"** parameter.

**i1P=CL:** the input is activated by closing the contact

**i1P=OP:** the input is activated by opening the contact

### 9. TTL SERIAL LINE - FOR MONITORING SYSTEMS

The TTL serial line, available through the HOT KEY connector, allows by means of the external TTL/RS485 converter, **XJ485-CX**, to connect the instrument to a monitoring system **ModBUS-RTU** compatible such as the **X-WEB500/3000/300**.


### 10. X-REP OUTPUT - OPTIONAL

As optional, an X-REP can be connected to the instrument, through the HOY KEY connector. The X-REP output **EXCLUDES** the serial connection.



To connect the X-REP to the instrument the following connectors must be used **CAB-51F(1m)**, **CAB-52F(2m)**, **CAB-55F(5m)**,

### 11. INSTALLATION AND MOUNTING



Instrument **XR40CX** shall be mounted on vertical panel, in a 29x71 mm hole, and fixed using the special bracket supplied.

The temperature range allowed for correct operation is 0-60 °C. Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. The same recommendations apply to probes. Let air circulate by the cooling holes.

### 12. ELECTRICAL CONNECTIONS

The instrument is provided with screw terminal block to connect cables with a cross section up to 2,5 mm². Before connecting cables make sure the power supply complies with the instrument's

requirements. Separate the probe cables from the power supply cables, from the outputs and the power connections. Do not exceed the maximum current allowed on each relay, in case of heavier loads use a suitable external relay.

### 12.1 PROBE CONNECTION

The probes shall be mounted with the bulb upwards to prevent damages due to casual liquid infiltration. It is recommended to place the thermostat probe away from air streams to correctly measure the average room temperature. Place the defrost termination probe among the evaporator fins in the coldest place, where most ice is formed, far from heaters or from the warmest place during defrost, to prevent premature defrost termination.

### 13. HOW TO USE THE HOT KEY

#### 13.1 HOW TO PROGRAM A HOT KEY FROM THE INSTRUMENT (UPLOAD)

1. Program one controller with the front keypad.
2. When the controller is ON, insert the **"Hot key"** and push **▲** key; the **"uPL"** message appears followed a by flashing **"End"**
3. Push **"SET"** key and the **End** will stop flashing.
4. Turn OFF the instrument remove the **"Hot Key"**, then turn it ON again.

**NOTE** the **"Err"** message is displayed for failed programming. In this case push again **▲** key if you want to restart the upload again or remove the **"Hot key"** to abort the operation.

#### 13.2 HOW TO PROGRAM AN INSTRUMENT USING A HOT KEY (DOWNLOAD)

1. Turn OFF the instrument.
2. Insert a programmed **"Hot Key"** into the 5 PIN receptacle and then turn the Controller ON.
3. Automatically the parameter list of the **"Hot Key"** is downloaded into the Controller memory, the **"dol"** message is blinking followed a by flashing **"End"**.
4. After 10 seconds the instrument will restart working with the new parameters.
5. Remove the **"Hot Key"**.

**NOTE** the message **"Err"** is displayed for failed programming. In this case turn the unit off and then on if you want to restart the download again or remove the **"Hot key"** to abort the operation.

### 14. ALARM SIGNALS

Message	Cause	Outputs
"P1"	Room probe failure	Compressor output acc. to par. "Con" and "COF"
"P2"	Evaporator probe failure	Defrost end is timed
"P3"	Third probe failure	Outputs unchanged
"P4"	Fourth probe failure	Outputs unchanged
"HA"	Maximum temperature alarm	Outputs unchanged
"LA"	Minimum temperature alarm	Outputs unchanged
"HA2"	Condenser high temperature	It depends on the "Ac2" parameter
"LA2"	Condenser low temperature	It depends on the "bLL" parameter
"dA"	Door open	Compressor according to rtd
"EA"	External alarm	Output unchanged
"CA"	Serious external alarm (i1F=bAL)	All outputs OFF
"CA"	Pressure switch alarm (i1F=PAL)	All outputs OFF

#### 14.1 ALARM RECOVERY

Probe alarms **"P1"**, **"P2"**, **"P3"** and **"P4"** start some seconds after the fault in the related probe, they automatically stop some seconds after the probe restarts normal operation. Check connections before replacing the probe.

Temperature alarms **"HA"**, **"LA"** **"HA2"** and **"LA2"** automatically stop as soon as the temperature returns to normal values.

Alarms **"EA"** and **"CA"** (with i1F=bAL) recover as soon as the digital input is disabled.

Alarm **"CA"** (with i1F=PAL) recovers only by switching off and on the instrument.

#### 14.2 OTHER MESSAGES

Pon	Keyboard unlocked
PoF	Keyboard locked
noP	In programming mode: none parameter is present in Pr1
	On the display or in dp2, dp3, dp4: the selected probe is not enabled
noA	None alarm is recorded.

### 15. TECHNICAL DATA

**Housing:** self extinguishing ABS.

**Case:** XR40CX frontal 32x74 mm; depth 60mm;

**Mounting:** XR40CX panel mounting in a 71x29mm panel cut-out

**Protection:** IP20, **Frontal protection:** XR40CX IP65

**Connections:** Screw terminal block ≤ 2,5 mm² wiring.

**Power supply:** according to the model: 12Vac/dc, ±10%; 24Vac/dc, ±10%; 230Vac, ±10%, 50/60Hz, 110Vac ±10%, 50/60Hz

**Power absorption:** 3VA max

**Display:** 3 digits, red LED, 14,2 mm high; **Inputs:** Up to 4 NTC or PTC probes.

**Digital input:** free voltage contact

**Relay outputs:** compressor SPST 8(3) A, 250Vac; or 20(8) A 250Vac

**defrost:** SPDT 8(3) A, 250Vac

**Data storing:** on the non-volatile memory (EEPROM).

**Kind of action:** 1B; **Pollution grade:** 2; **Software class:** A;

**Rated impulsive voltage:** 2500V, **Overvoltage Category:** II

**Operating temperature:** 0-60 °C; **Storage temperature:** -30-85 °C.

**Relative humidity:** 20-95% (no condensing)

**Measuring and regulation range:** **NTC probe:** -40-110°C (-40-230°F);

**PTC probe:** -50-150°C (-58-302°F)


**Resolution:** 0,1 °C or 1 °C or 1 °F (selectable); **Accuracy (ambient temp. 25°C):** ±0,7 °C ±1 digit



## 16. CONNECTIONS


The X-REP output excludes the TTL output. It's present in the following codes:  
XR40CX-xx2xx, XR40CX-xx3xx;

### 16.1 XR40CX – 8A COMPRESSOR



12Vac/dc supply connect to the terminals 7 and 8.  
24Vac/dc supply connect to the terminals 7 and 8.  
120Vac supply connect to the terminals 7 and 8.

### 16.2 XR40CX – 20A COMPRESSOR



12Vac/dc supply connect to the terminals 7 and 8.  
24Vac/dc supply connect to the terminals 7 and 8.  
120Vac supply connect to the terminals 7 and 8.

## 17. DEFAULT SETTING VALUES

Label	Name	Range	°C/°F	
Set	Set point	LS=US	-5.0	---
Hy	Differential	0.1÷25.5°C / 1÷255°F	2.0	Pr1
LS	Minimum set point	-50°C+SET/-58°F+SET	-50.0	Pr2
US	Maximum set point	SET+110°C / SET+230°F	110	Pr2
Ot	Thermostat probe calibration	-12÷12°C / -120÷120°F	0.0	Pr1
P2P	Evaporator probe presence	n=not present, Y=pres.	Y	Pr1
OE	Evaporator probe calibration	-12÷12°C / -120÷120°F	0.0	Pr2
P3P	Third probe presence	n=not present, Y=pres.	n	Pr2
O3	Third probe calibration	-12÷12°C / -120÷120°F	0	Pr2
P4P	Fourth probe presence	n=not present, Y=pres.	n	Pr2
O4	Fourth probe calibration	-12÷12°C / -120÷120°F	0	Pr2
Ods	Outputs delay at start up	0÷255 min	0	Pr2
AC	Anti-short cycle delay	0÷50 min	1	Pr1
rtr	P1-P2 percentage for regulation	0÷100 (100=P1, 0=P2)	100	Pr2
Cct	Continuous cycle duration	0÷24.0h	0.0	Pr2
CCS	Set point for continuous cycle	(-55.0÷150.0°C) (-67÷302°F)	-5	Pr2
Con	Compressor ON time with faulty probe	0÷255 min	15	Pr2
COF	Compressor OFF time with faulty probe	0÷255 min	30	Pr2
CF	Temperature measurement unit	°C ÷ °F	°C	Pr2
rES	Resolution	in=integer, dE=dec point	dE	Pr1
LoD	Probe displayed	P1;P2	P1	Pr2
rEdP	X-REP display	P1 - P2 - P3 - P4 - SET - dtr	P1	Pr2
dLy	Display temperature delay	0÷20.0 min (10 sec)	0	Pr2
dtr	P1-P2 percentage for display	1÷99	50	Pr2
tdF	Defrost type	EL=el. heater, in=hot gas	EL	Pr1
dFP	Probe selection for defrost termination	nP; P1; P2; P3; P4	P2	Pr2
dTE	Defrost termination temperature	-50÷50 °C	8	Pr1
IdF	Interval between defrost cycles	1÷120 one	6	Pr1
MDf	(Maximum) length for defrost	0÷255 min	30	Pr1
dSd	Start defrost delay	0÷99 min	0	Pr2
dFd	Displaying during defrost	rt; it; SET; DEF	it	Pr2
dAd	MAX display delay after defrost	0÷255 min	30	Pr2
Fdt	Draining time	0÷120 min	0	Pr2
dPo	First defrost after startup	n=after IdF, y=immed.	n	Pr2
dAF	Defrost delay after fast freezing	0÷23h e 50'	0.0	Pr2
ALc	Temperat. alarms configuration	rE= related to set; Ab= absolute	Ab	Pr2
ALU	MAXIMUM temperature alarm	Set+110.0°C; Set+230°F	110	Pr1
ALL	Minimum temperature alarm	-50.0°C+Set/-58°F+Set	-50.0	Pr1
AFH	Differential for temperat. alarm recovery	(0.1°C÷25.5°C) (1°F÷45°F)	1	Pr2
ALd	Temperature alarm delay	0÷255 min	15	Pr2
dAO	Delay of temperature alarm at start up	0÷23h e 50'	1.3	Pr2
AP2	Probe for temperat. alarm of condenser	nP; P1; P2; P3; P4	P4	Pr2
AL2	Condenser for low temperat. alarm	(-55÷150°C) (-67÷302°F)	-40	Pr2
AU2	Condenser for high temperat. alarm	(-55÷150°C) (-67÷302°F)	110	Pr2
AH2	Differ. for condenser temp. alar. recovery	(0.1°C÷25.5°C) (1°F÷45°F)	5	Pr2
Ad2	Condenser temperature alarm delay	0÷254 (min.) , 255=nU	15	Pr2
dA2	Delay of cond. temper. alarm at start up	0.0÷23h 50'	1.3	Pr2
bLL	Compr. off for condenser low temperature alarm	n(0) - Y(1)	n	Pr2
AC2	Compr. off for condenser high temperature alarm	n(0) - Y(1)	n	Pr2
I1P	Digital input polarity	oP=opening, CL=closing	cL	Pr1
i1F	Digital input configuration	EAL, bAL, PAL, dor, dEF; Hlr, AUS	EAL	Pr1
did	Digital input alarm delay	0÷255min	5	Pr1
Nps	Number of activation of pressure switch	0÷15	15	Pr2
odc	Compress status when open door	no; Fan; CPr; F; C	no	Pr2
rrd	Regulation restart with door open alarm	n - Y	y	Pr2
HES	Differential for Energy Saving	(-30°C÷30°C) (-54°F÷54°F)	0	Pr2
Adr	Serial address	0÷247	1	Pr2
PbC	Kind of probe	Pb; ntc	ntc	Pr2
onF	on/off key enabling	nu, off; ES	nu	Pr1
dP1	Room probe display	--	--	Pr2
dP2	Evaporator probe display	--	--	Pr2
dP3	Third probe display	--	--	Pr1
dP4	Fourth probe display	--	--	Pr1
rSE	Valore set operativo	actual set	--	Pr1
rEL	Software release	--	--	Pr2
Ptb	Map code	--	--	Pr2

2 Only for models XR40CX-xx2xx, XR40CX-xx3xx;

Dixell S.p.A. - Z.I. Via dell'Industria, 27  
32010 Pieve d'Alpago (BL) ITALY  
tel. +39 - 0437 - 98 33 - fax +39 - 0437 - 98 93 13  
E-mail: dixell@dixell.com - http://www.dixell.com

